




Video Conference Wireless Microphone & Speaker VC2000W



For further information, please visit / contact us on:

Tel: (RSA) 010 140 4900 / Email: sales@parrot.co.za / www.parrot.co.za

Content

Product Description

Speakerphone.....1

Parts list.....1

Optional Accessories.....2

Speakerphone Interface Specification.....2

Extension Unit (Optional).....2

Speakerphone Introduction.....3

The USB/Wireless devices Keypad3

LED Status Indicator.....3

The Bluetooth devices Keypad.....4

LED Status Indicator.....5

How to Use Speakerphone.....6


Wireless Connection.....6

In/Out Connection.....7

Installation and Use of Extension Unit (Optional).....8


**Please Note Bluetooth Not Applicable To This
Product Version (VC2000W)**

Speakerphone




Bluetooth device


Parts list



USB Cable




User manual




**Power adapter
(The Wireless device supplied)**


Accessories



5m RJ45 Cable




Extension Unit




4-Strand
3.5MM Cable

If any items are missing or damaged, contact your place of purchase immediately.
Do not use damaged products!

Interface Specification




Extension Unit (Optional)




Introduction

The USB/Wireless device Keypad




| | | |
|-----|------------------|----------------------------|
| — + | Volume button | Turn down/up the volume |
| x | Speaker Mute | Turn on/o the speaker |
| 📞 | Answer/End calls | Answer/End calls |
| 🎤 | Mute Microphone | Turn on/off the Microphone |

LED Status Indicator




| | | |
|--|----------------------|--|
| Power status indicator | Green light on | Speakerphone working normally |
| Wireless status indicator (The Wireless device apply) | Green light flashing | Wireless pairing state |
| | Green light on | Wireless connected |
| Working status indicator/ Volume status indicator | Red light on | Microphone mute |
| | Green light on | Microphone working normally/The brightness of status LED will increase or decrease with the speaker volume up or down. |
| | Green light flashing | Speaker mute |
| Microphone Status indicator | Red light on | Microphone mute |
| | Green light on | Microphone working normally |

The Bluetooth device Keypad



| | | |
|------------------|------------------|----------------------------|
| — + | Volume button | Turn down/up the volume |
| Bluetooth symbol | Bluetooth button | Turn on/off the Bluetooth |
| Call icon | Answer/End calls | Answer/End calls |
| Microphone icon | Mute Microphone | Turn on/off the Microphone |

LED Status Indicator



| | | |
|--|----------------------|--|
| Power status indicator | Red light on | Low battery, must be recharged |
| | Green light flashing | Charging |
| | Green light on | The battery is fully charged. |
| Bluetooth status indicator | Green light flashing | Bluetooth pairing state |
| | Green light on | Bluetooth connected |
| Working status indicator/ Volume status indicator | Red light on | Microphone mute |
| | Green light on | Microphone working normally/The brightness of status LED will increase or decrease with the speaker volume up or down. |
| | Green light flashing | Speaker mute |
| Microphone Status indicator | Red light on | Microphone mute |
| | Green light on | Microphone working normally |

How to Use

Connection Steps for USB

1. Using the supplied USB cable; Connect one end of the USB cable to the, speakerphone and the other end to the computer or other communication device
2. Turn on the power switch after confirming the correct connection on; It will take a few seconds to install the driver automatically for the first setup, the computer prompts the drive installation success. After confirming that all connections are correct, open the third-party conference software, and select the microphone and speaker driver to start the audio and video conference with the device.

Common Reference Settings for PC and Video Devices with USB Talking Mode:

1. Please adjust the volume of speaker and microphones comprehensively to ensure the communication is clear and smooth.
2. Don't turn on the speaker and microphone automatic gain.
3. Give priority to turning off the audio processing functions of the PC software / video software (such as turning off automatic gain, echo cancellation, noise , reduction etc.).
4. Please use the speech / audio settings highest that has a higher sound quality

LED Status Indicator

| | | |
|-----------------------|------------------------|--|
| Adaptor LED indicator | light flashing quickly | The device searches for pairing status |
| | light flashing slowly | The connection is successful |

Keypad

| | | |
|----------------------|-------------------------|-------------------------------------|
| Adaptor control keys | Double click on the key | The device enters the pairing state |
| | long press 5 seconds | Clear pair record |

Bluetooth Connection (The Bluetooth device)

Once paired with a Bluetooth device, you can use the speakerphone for audio calls. To pair your Bluetooth device with the speakerphone, follow steps below:

1. Press and hold the “*” button until the Bluetooth Indicator green light flashes.
The speakerphone is in Bluetooth pairing mode.
2. Turn on the Bluetooth function of the mobile phone and click search.
3. Search “Device name” with your Bluetooth device and connect.
4. When the Bluetooth is set up, the Bluetooth indicator light will stay on.
Then you can use the speakerphone for audio call.
5. Press the “*” button to turn off Bluetooth.

Note:

When Bluetooth fails to connect within 40 seconds, Bluetooth needs to be restarted.

In/out Connection

Use a 3.5mm 4-strand cable to connect your phone or PC device to the "I/O" port of the speakerphone.

If the device connection port is a 3.5mm 3-strand port, you need a transfer adapter for connecting. Insert audio transfer plug into the "I/O" port of Speakerphone.

Connect the microphone port and speaker port of Audio Transfer plug to the IN/OUT port of the PC or video conferencing system with two 3.5mm 3-strand cable.


Note:

Please set the phone LINE IN/OUT mode to "PC Mode" when connecting PC or video devices. Set the phone LINE IN/OUT mode to "Mobile Mode" when connecting a smartphone.

Installation and Use of Extension Unit(Optional)


Please use the extension unit when you need a larger connection or essential meeting.

1. Connect EXT interface of the main speakerphone unit and extension unit by using the original RJ45 cable. Connect to PC, communication device or power supply via USB cable. After ensuring all connections are correct, switch on power supply.
2. The extension unit has a speaker and microphones system. Two units simultaneously working in the same space, double the cover space of meeting room and the number of participants. The sound of the main unit and the extension unit are completely synchronized, and they can control each other at the same time.
3. The extension unit has a mute switch and status indicator. The indicator is green when the microphone works normally, and red when muted.



Note:

Ensure the main unit is properly connected to the extension unit, before switching on.



Connection diagram