



## User Manual

# Video Conference Webcam Full HD - VC0001




Tel: (RSA) 010 140 4900 / Email: [sales@parrot.co.za](mailto:sales@parrot.co.za)  
[www.parrot.co.za](http://www.parrot.co.za)

## Introduction

This product is for real-time video calling and conferencing.

## Features

- ① Webcam
- ② Microphone
- ③ Manual Focus
- ④ Flexible Base/Clip
- ⑤ USB Cable
- ⑥ Tripod Screw Hole (Tripod is not included)
- ⑦ User Manual
- ⑧ **Four LED Lights (Provides light in darkness)**



## System Requirements

IBM PC or compatible PC or laptop with  
USB port Pentium 200 or higher CPU.  
Operation system: Windows XP/2000/2003/  
Vista/ 7/ 8/ 10, Mac OS, Android and Linux.

- Over 200MB available hard disk space
- 32MB or higher memory
- Support Direct X VGA card

**For use with any of the below devices:**



**PC Monitor**



**Laptop**



**Tripod**

## Parameters and Features


- High resolution CMOS color sensors
- Large window capture size: 640x480 / 800x600
- Video mode: 24bit true colour
- Interface: USB port
- Transmission rate:

320 x 240	30 FPS
640 x 480	30 FPS
1280 x 720	30 FPS
1920 x 1080	30 FPS
- Noise-signal ratio: greater than 48 dB  
(30 FPS 220LUX)
- Dynamic range: greater than 72 dB
- Image focus: 50cm to infinity
- Build-in image compression
- Automatic brightness adjustment
- Automatic color compensation
- Manual focus

### Built-in Four LED Lights

- Equipped with four LED lights to provide additional lighting in dark spaces
- On/off button switch is located on the rear of the webcam


**For positioning of webcam on a monitor:**



## **Connect the Webcam**

Connect the webcam to the computer via the USB cable supplied.

**Tip:** when using a desktop, it is better to connect the webcam to the fastest USB port on the computer for faster data transmission



## Care & Maintenance


1. Not recommended for use in extremely hot, cold, dusty or dry conditions.
2. In order to avoid lens damage, do not touch the lens directly or use sharp objects near the lens.
3. Caution should be practiced to avoid dropping the webcam.
4. Lens should be cleared using a soft, clean cloth.

## Warranty

This product is warranted by non-human factors covered by a carry-in warranty.

### **The warranty does not cover:**

- Abuse or negligence
- Repair or disassembled by other companies technicians.
- Damage due to dropping or impact.



**Once installation is complete, the webcam is ready for use.**

## **Manual Focus**

Manually rotate the lens until image is in focus.

