





User Manual
Extendable Ceiling
Mounted Projector Bracket
- OP0300




For further information, contact us on:
Tel: (RSA) 010 140 4900 / Email: sales@parrot.co.za /
www.parrot.co.za




A (x1)



B (x1)



C (x1)



D (x1)



E (x1)



M5x10 (x6)
M-A



M6x10 (x4)
M-B



M5x8 (x4)
M-C



M4x8 (x4)
M-D



M3x8 (x4)
M-E



D3 (x4)
M-F



D4 (x4)
M-G



D5 (x10)
M-H



D5 (x2)
M-I




D6 (x4)
M-J



4mm (x1)
M-K




5mm (x1)
M-L



94mm (x2)
M-M




ST6.3x55 (x4)
W-A




W-B (x4)



D8 (x4)
W-C


 Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.

 **CAUTION:** Use with products heavier than the rated weights indicated may result in instability causing possible injury.


- Mounts must be attached as specified in assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- This product is designed to be installed on wood joist ceiling or concrete ceiling.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and **DO NOT OVER TIGHTEN** mounting screws
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, telephone your local distributor for a replacement.



MAINTENANCE: Check that the bracket is secure and safe to use at regular intervals (at least every three months).






4






5



- 1
 - 2
 - 3
-



7



-15° ~ 15°

8