IW7102: Interactive Touch Panel Mobile Stand

■ Product Structure

C Panel x1

D   Mounting Patterns x2

B Column (R) x1

A Column (L) x1

Height-adjustable

F Caster (with brake)   E   Shelf x1

F Caster (with brake)

F Caster (with brake)

F Caster (with brake)

■ Parts list

|			
Column (L)	A x 1	Screws (M8)	H x 4
Column (R)	B x 1	Hexagon Wrench (5mm)	I x 1
Screws (M6)	C x 1	Screws (M6)	J x 6
Hexagon Wrench (4mm)	D x 2	Hexagon Wrench (4mm)	K x 1
Open End Wrench (19mm)	E x 1	Open End Wrench (19mm)	L x 1
Open End Wrench (19mm)	F x 4		

■ Step-1

I
H

K
J J
J J

H

Proper gap >5mm

A

B

Caution: no need to screw firmly, proper gap between column and screw is supposed to be obligated, for a convenient subsequent assembly

■ Step-2

C

A

Forward own

Attention to the direction of the hanging rack

B

Hung down the screw to the small hole.

The screw should be put through and hung down from the large hole to the small hole.

■ Step-3

H
I
H

Caution: no need to screw firmly, for a convenient subsequent assembly.

### Warning!
- If you do not understand the instruction or have any concerns or questions, please contact a qualified local installer.
- Do not use this products for anything other than the original design
- This products contains moving parts, please use with caution
- All images are for reference, to prevail in products

Step-4

Hang the upper screw

E

Then the lower one

Step-5

J

J

K

J

K

First, tighten the upper part

Then, tighten the lower part

K

Caution: make sure the cart is put on the level ground, each component is on the right position. Then tighten the screws in sequence.

■ Step-7

L

F

F

F

F

Put down the cart

D

Tighten the screws by cross screwdriver after TV interface installation